

03.102 CDRA LiOH Canister Swapout (03. ECLSS)

OBJECTIVE:

To replace the Lithium Hydroxide (LiOH) Canister Assembly on the Carbon Dioxide Removal Assembly (CDRA).

EQUIPMENT:

LiOH canister (will be gathered during the procedure)
Flashlight
Shop vacuum
Portable anemometer
PPE safety glasses
PPE Kobalt work gloves
PPE static wrist tether
Orange caution cone 2x

NOTE

The CDRA requires the use of the Fan Dampener Assembly (FDA) for proper operation. The assembly prevents particulate matter from interfering with the infrared sensor and damaging the sampling pump. If the filter becomes clogged, the assembly must be replaced.

L1F Subf 1. DEACTIVATE MAIN CABIN FANS (IF ACTIVATED)

- 1.1 Don PPE gloves and safety glasses.
- 1.2 Remove floor panel 1F and temp stow.



Figure 1: Cabin Fan Power Switches

- 1.3 On Main Cabin Fan, pull switch out and push toward “OFF” to deactivate fan (see Figure 1).

03.102 CDRA LiOH Canister Swapout (03. ECLSS)

Verify fan has audibly shut off.

- 1.4 On Secondary Cabin Fan, pull switch out and push toward “OFF” to deactivate fan (see Figure 1).

Verify fan has audibly shut off.

- 1.5 Place orange caution cone next to open work area L1F subfloor to warn other crewmembers.

GMWS 2. DEACTIVATE AUX CABIN FANS (IF ACTIVATED)



Figure 2: Trace Contaminant Control Subassembly (TCCS) Panel

- 2.1 On TCCS Panel, check power switches of Aux Cabin Fan 1 and Aux Cabin Fan 2 are “OFF” (see Figure 2).
 - 2.1.1 Move stowage as necessary in order to access the TCCS Panel.
 - 2.1.2 If power switches of Aux Cabin Fan 1 and Aux Cabin Fan 2 are **NOT** “OFF”, flip each switch to “OFF”.

L1D Subf 3. DEACTIVATE FAN DAMPENER ASSEMBLY (FDA) PUMP (IF ACTIVATED)

- 3.1 Remove floor panel 1D and temp stow.
- 3.2 Don static wrist tether and attach to any unpainted metallic surface.

03.102 CDRA LiOH Canister Swapout (03. ECLSS)




Figure 3: Fan Dampener Assembly (FDA) Pump

- 3.3 Turn FDA Pump Power Dial counterclockwise to “OFF” (see Figure 3). Listen for a click.

NOTE

Read step 3.5 before executing 3.4. Step 3.5 is time dependent and can be missed if not actively watching the Dampener Dial.

- 3.4 Flip Air Flow Dampener switch to “Closed”.
- 3.5 Confirm Dampener Dial Indicator (metal Philips head screw with spring attached) rotates to fully closed (see Figure 3).
- 3.6 Detach static wrist tether.
- 3.7 Place orange caution cone next to open work area L1D subfloor to warn other crewmembers.

03.102 CDRA LiOH Canister Swapout (03. ECLSS)

L1C Subf

4. REMOVE USED LiOH CANISTER



Figure 4: LiOH Canister Assembly

- 4.1 Remove LiOH Canister Cover and temp stow (see Figure 4).
- 4.2 Don static wrist tether and attach to unpainted metallic surface.
- 4.3 Remove LiOH Canister from filter assembly (see Figure 4).
- 4.4 Inspect filter assembly with flashlight for debris and clean as necessary with shop vacuum.
- 4.5 Gather portable anemometer and take reading in m/s of filter assembly air flow at the LiOH canister entrance. Hold anemometer within an inch of the LiOH canister entrance for 10 seconds to gather an accurate reading and report the highest reading to MCC.
- 4.6 Confirm with MCC that the filter assembly flow at the LiOH canister entrance is within expected range.
- 4.7 **On MCC GO**

Notify MCC of used LiOH Canister S/N.
- 4.8 Doff static wrist tether.
- 4.9 Label used LiOH Canister with sticky note and stow in consumables drawer in ALC L01.

03.102 CDRA LiOH Canister Swapout
(03. ECLSS)

ALC

5. RETRIEVE CLEAN LiOH CANISTER



Figure 5: LiOH Canister

- 5.1 Remove clean LiOH Canister from ALC L01 (see Figure 5).
- 5.2 Inspect clean LiOH Canister with flashlight for debris and clean as necessary.

L1C Subf

6. INSERT CLEAN LiOH CANISTER

- 6.1 Don static wrist tether and attach to unpainted surface.
- 6.2 Inspect interior of hose and filter assembly with flashlight for debris and clean as necessary with shop vacuum.
- 6.3 Insert clean LiOH Canister into filter assembly.
- 6.4 Detach static wrist tether from unpainted surface.
- 6.5 Notify MCC of clean LiOH Canister S/N.
- 6.6 **On MCC GO**

Replace LiOH Canister cover and safely latch.

L1D Subf

7. ACTIVATE FDA PUMP

NOTE

FDA Pump Power Dial can be set from Low to High. When on, always leave dial set to High.

- 7.1 Attach static wrist tether to any unpainted surface.
- 7.2 Flip Air Flow Dampener switch to “OPEN” (see Figure 3).
 - 7.2.1 Check that the Dampener Dial Indicator (metal Philips head screw with spring attached) rotates to fully open (see Figure 3).

03.102 CDRA LiOH Canister Swapout (03. ECLSS)

7.3 Turn FDA Pump Power Dial to “ON” by rotating clockwise. After hearing click, stop rotation. Verify dial is set to “HIGH” position (see Figure 3).

7.4 Detach static wrist tether.

L1F Subf 8. ACTIVATE MAIN CABIN FANS

8.1 On Main Cabin Fan, pull switch out and push toward “ON” to activate fan (see Figure 1).

Verify fan has audibly turned on.

8.2 On Secondary Cabin Fan, pull switch out and push toward “ON” to activate fan (see Figure 1).

Verify fan has audibly turned on.

8.3 Replace floor panel 1F and safely latch.

9. ECLSS VENT CHECK



Figure 6: Cabin Output Vent C/D



Figure 7: Cabin Output Vent D/E

9.1 Gather portable anemometer and take readings in m/s of exhaust flow at cabin output vents C/D and D/E (Figures 6 and 7). Hold anemometer within an inch of the vent for 10 seconds to gather an accurate reading and report the highest reading to MCC.

03.102 CDRA LiOH Canister Swapout

(03. ECLSS)

- 9.2 Call MCC to confirm air flow is within expected range by reporting the flow. (Reading should be greater than 0.5 m/s.)
- 9.3 **On MCC GO**, relocate floor panel 1D and safely latch.
- 9.4 Doff PPE Kobalt work gloves, static wrist tether, and safety glasses.
- 9.5 Stow all equipment including orange caution cones.